



Any point Marked **(LxT/831)** are specific to the Model 831 and Soundtrack LxT® Sound Level Meters. For these meters, it is required that the latest version of the SLM Utility G3 be install from the Larson Davis web site.

DNA 4.3 does not require that the previous versions of DNA be removed from the computer.

1. Remove all USB Dongles from the PC
2. Remove all USB Analyzers from the PC
3. Execute the installer to start
 - a. If using SLM Utility G3 CD this can be found in **D:\Demo Software\DNA 4.3.5.0\DNA\setup.exe**. Replace D: with the appropriate drive letter of your CDROM if needed.
 - b. If installing from a zip file downloaded from the Internet, first unzip the file and then run **setup.exe** inside the unzipped folder.
 - c. If using a DNA CD the installation should start automatically. If not, run **D:\DNA\CD.exe**. Replace D: with the appropriate drive letter of your CDROM if needed.
4. Follow the instructions of the Setup program and enter all of the requested data, including analyzer selection.
5. (LxT/831) It is possible that the setup program terminates before ending all operations with a request to reboot the PC. In this case manually reboot the PC, and after the PC has restarted, execute the setup program again. In rare cases it is possible for the reboot to occur twice.
6. At the end of the installation, insert the USB dongle Key. Windows should find the Drivers automatically.
7. (LxT/831) Connect the instrument to the USB port. The instrument must be in an OFF state.
8. (LxT/831) Turn ON the Instrument. This will begin driver installation. When a new (a meter that has not been connected to the computer since the last installation) LxT or the 831 are connected to a computer, Windows should start its find new hardware process:
 - a. Select "Install from a list or specific location" (Advanced) and click "Next".
 - b. Next, Windows will ask you to choose how to find the drivers. Please Select "Don't search, I will Choose the driver to install and click "Next".



- c. Next you will select your driver. If the “Larson Davis Model 831 & Soundtrack LxT “ is not an option on the list, click on the “Have Disk...” button and browse to the directory below:
- d. C:\Program Files\PCB Piezotronics\DNA4\SETUP\LD SIm USB Drivers
- e. Highlight the driver and click “Next”. Installation should occur and windows should give you the “Your new hardware is installed and ready to use” Message. From here you will be able to connect using the SLMScreenGrabber, SLM Utility G3, and DNA 4.3.5.0