

NoiseTutor Quick Start Guide

I. NoiseTutor Station Deployment

1. Unpack the NoiseTutor Station and accessories (microphone preamplifier, etc.). Remove plastic cover from display.
2. If not installed, insert SIM card into cellular modem as shown on Installation Reference diagram located on inside case of NoiseTutor Station.
3. If not installed, mount Model 831 into NoiseTutor station as shown in diagram located on inside case.
4. Connect and mount preamplifier with microphone to microphone cable.
5. Plug-in AC power cable.
6. Remove top plate as shown in diagram located on inside case and press black power switch to start system.
7. Press monitor power button once to activate display.
8. Turn on keyboard power (switch on back of keyboard).
9. Refer to NoiseTutor System Manual for NoiseTutor System Software configuration instructions.

Component Checklist

- Model 831 installed
- SIM card installed
- License file installed

II. Web-Server Installation and configuration

1. Insert NoiseTutor Server and Manual CD.
2. Follow the NoiseTutor System Manual for Web-server set-up and configuration instructions.